



# H97I-PLUS Repair Guide


## BLOCK DIAGRAM



## POWER ON SEQUENCE



## Frequency Flow






## Voltage Measure Point

multi meter "V  $\Omega$  mA" port touch here

Pink number is Diode resistance to GND(without any part on MB)multimeter type DH-1240





# Signal Measure Point

