





BLOCK DIAGRAM



POWER FLOW




POWER ON SEQUENCE



Pink number is Diode resistance to GND(without any part on MB)multimeter type DH-1240

Frequency Flow Voltage Measure Point

multi meter “VΩ mA” port touch here



Signal Measure Point

