



CROSSHAIR V FORMULA

Revision: 2011.01.6
1.00




WWW.AITECH1.RU


POWER FLOW



POWER ON SEQUENCE




Frequency Flow




Pink number is the GND diode resistance (without any part on MB)multimeter type DH-1240

Voltage Measure Point

multi meter "VΩ mA" port touch here



Signal Measure Point



Signal Measure Point

