



K56CM Repair Guide

K56CM SCHEMATIC R1.1(CR)




POWER FLOW



POWER ON SEQUENCE

U53 Power On Sequence Diagram Rev.0.14



Voltage & Signal Measure Point TOP



Voltage & Signal Measure Point Bottom

