


# K72F Repair Guide

2010/03/02  
Janmouss\_chang  
CSC-GRMA

PAGE	Content
1	Block Diagram
2	System Setting
3	CPU(1)_DMI, FEG, FDI, CLK, MISC
4	CPU(2)_DDR3
5	CPU(3)_CFG, RSVD, GND
6	CPU(4)_PWR
7	CPU(5)_VDD
16	DDR3 SO-DIMM_0
17	DDR3 SO-DIMM_1
18	DDR3 CA_DQ VOLTAGE
19	VID controller
20	PCB_I2EX(1)_SATA, INDA, RTC, LPC
21	PCB_I2EX(2)_FCID, CLK, SMC, FEG
22	PCB_I2EX(3)_FDI, IMI, SYS_PWR
23	PCB_I2EX(4)_CP, LVDS, CRT
24	PCB_I2EX(5)_PCI, WTRAM, USB
25	PCB_I2EX(6)_CPU, GPIO, MISC
26	PCB_I2EX(7)_POWER, GND
27	PCB_I2EX(8)_POWER, GND
28	PCB_SFI ROM, OTH
29	CLK_IC93LVDS162ENLFT
30	EC_IT870(1/2)
31	EC_IT870(2/2)KB, TP
32	RST_Reset Circuits
33	LAM_A98191
34	LAM_R745
36	CODEC-INT92H079
37	AUD_Amp & Jack
38	Internal MIC
39	SPEAKER
42	B to B Connector
44	BUG_Debug
45	CRT_LCD Panel
46	CRT_P-Sub
48	TV_SDMI
50	FAN_Fan & Sensor
51	KDD_HDD & ODD
52	USB_USB Port *2
53	MINICARD (WLAN)
56	LED_Indicator
57	DBG_Discharge
58	FWRSD DETECTOR
60	DC_DC & BAT Conn.
61	BT Bluetooth
64	MINICARD
65	ME Conn & Shew Hole
67	PCB_XDP, ONFI
80	FW_VCORE(MCF3218)
81	FW_SYSTEM(RT8206A)
82	FW_I/O_VCCP(RT8202A)
83	FW_I/O_DDR(RT8202A+eP7711)
84	FW_LOAD_+1_VVS(RT8015EGQW)
86	POWER_VOPX_CORE(RT8182DGQW)
86	POWER_CHARGER(MB39A132)
91	FW_LOAD SWITCH
91	FW_SIGNAL
94	FW_FLOWCHART

## K72F Schematic R2.1




# K72F Repair Guide

2010/03/02  
Janmouss\_chang  
CSC-GRMA

AC-IN Mode

K72F Power On Sequence Diagram Rev. 2.0




Power On Sequence


1 → 24

# K72F Repair Guide

2010/03/02  
Janmou\_chang  
CSC-GRMA




2010/03/02  
Janmous\_chang  
CSC-GRMA



# K72F Repair Guide


2010/03/02  
Janmouss\_chang  
CSC-GRMA



# K72F Repair Guide


2010/03/02  
Janmous\_chang  
CSC-GRMA

## DC-IN Mode



# K72F Repair Guide(Top)

2010/03/02  
Janmou\_chang  
CSC-GRMA



# K72F Repair Guide(Bottom)

2010/03/02  
Janmous\_chang  
CSC-GRMA

