

U50F Repair Guide


2009/11/16
Janmouss_chang
CSC-GRMA

SYSTEM PAGE REF.


U50F Main Board Schematics

BLOCK DIAGRAM

PAGE	Content
1	Block Diagram
2	System Setting
3	CPU(1)_DMI,PEG,FDI,CLK,MISC
4	CPU(2)_DDR3
5	CPU(3)_CFG,RSVD,GND
6	CPU(4)_PWR
7	CPU(5)_HDP
16	DDR3 SO-DIMM_0
17	DDR3 SO-DIMM_1
18	DDR3 CA_DQ VOLTAGE
19	VID controller
20	PCIE_INDEX(1)_SATA,IDEA,PC,IPC
21	PCIE_INDEX(2)_PCI,CLK,SUB,PEG
22	PCIE_INDEX(3)_PCI,DMI,SYS PWR
23	PCIE_INDEX(4)_DP,LVDS,CRT
24	PCIE_INDEX(5)_PCI,MVRAM,USB
25	PCIE_INDEX(6)_CPU,GPIO,MISC
26	PCIE_INDEX(7)_POWER,GND
27	PCIE_INDEX(8)_POWER,GND
28	PCIE_SPT ROM,OTH
29	CLK_IC931FR62
30	EC_IT8541(1/2)
31	EC_IT8541(2/2)KE,TP
32	Reset Circuit
33	HANKSVILLE
34	LAN_RP40
35	CODEC-ALC660
36	AUD_Amp & Jack
37	AUT_FMR10
38	CE_R5C820
39	CE_R5C820
40	CE_R5C820
41	CE_R5C820
42	CE_4in1 CardReader
43	CE_MemCard
44	DOG_Debug
45	CRT_LCD Panel
46	CRT_D-Sub
47	Display Port
48	TV HDMI
50	FAN_Fan & Sensor
51	XDD_HDD & GDD
52	USB_USB_F+ & 2
53	MINICARD(WLAN)
54	LED_Indicator
57	DOG_Discharge
60	DC_DC & BATT.Conn.
61	BT_Bluetooth
64	TUN_TV Tuner
65	ME_Conn & Skew Hole
66	ESA_****
67	PCIE_XDP, ONFI
70	VGA_HDMI
71	VGA_LVDS Switch
80	FW_VCORE(MX17084)
81	FW_SYSTEM(MX17020)
82	FW_I/O_VTT_CPU+1.1VM
83	FW_I/O_VTT_DDR+VTT+1.5VS
84	FW_I/O_VTM & ME_VTM_PWEGD
85	FW_VOTM_CORE(MX17020)
86	FW_CHARGER(MX17010)
87	FW_DETECT
88	FW_LOAD SWITCH




2009/11/16
Janmous_chang
CSC-GRMA



2009/11/16
Janmous_chang
CSC-GRMA

AC-IN Mode

M52J Power On Sequence Diagram Rev. 0.31



U50F Repair Guide(TOP)

2009/11/16
Janmous_chang
CSC-GRMA



U50F Repair Guide(Bottom)

2009/11/16
Janmous_chang
CSC-GRMA

