


UN42 Repair Guide

OCT/30 2014


KELLY

GTSD


BLOCK DIAGRAM



POWER FLOW




POWER ON SEQUENCE




Voltage Measure Point (top side)

multi meter "VΩ mA" port touch GND


Pink number is Diode resistance to GND(without any part on MB)multimeter type DH-1240



Voltage Measure Point (bottom side)



Signal Measure Point(top side)



Signal Measure Point (bottom side)

