


UN62 Repair Guide

NOV/13 2014


KELLY

GTSD


BLOCK DIAGRAM



POWER FLOW




POWER ON SEQUENCE




Voltage Measure Point (top side)

multi meter “V Ω mA” port touch GND


Pink number is Diode resistance to GND(without any part on MB)multimeter type DH-1240



Voltage Measure Point (bottom side)



Signal Measure Point(top side)



Signal Measure Point (bottom side)

