



X45A Repair Guide

X45A Block Diagram




POWER FLOW




POWER ON SEQUENCE

U53 Power On Sequence Diagram Rev.0.14



Voltage & Signal Measure Point TOP



1091f

