



X45U Repair Guide


X45U Schematic R1.0




POWER FLOW



POWER ON SEQUENCE



Voltage & Signal Measure Point TOP



Voltage & Signal Measure Point Bottom

