



# K46CM Repair Guide

## BLOCK DIAGRAM

### K46VM SCHEMATIC R1.0




# POWER FLOW




# POWER ON SEQUENCE

U53 Power On Sequence Diagram Rev.0.14



## Voltage & Signal Measure Point TOP





## Voltage & Signal Measure Point Bottom

