




# POWER FLOW



# POWER ON SEQUENCE



# Frequency Flow






Pink number is the GND diode resistance (without any part on MB)multimeter type DH-1240

## Voltage Measure Point

multi meter "VΩmA" port touch here





## Signal Measure Point

