




POWER FLOW



POWER ON SEQUENCE




Frequency Flow



Pink number is the GND diode resistance (without any part on MB)multimeter type DH-1240

multi meter "V Ω mA" port touch here

Voltage Measure Point



Signal Measure Point

