



H81M-PLUS Repair Guide

07/24 2013
Leilei52_Chen
CSC-GRMA


BLOCK DIAGRAM




POWER FLOW



POWER ON SEQUENCE




Frequency Flow



Voltage Measure Point

multi meter " $V \Omega mA$ " port touch here

Pink number is Diode resistance to GND(without any part on MB)multimeter type DH-1240



Signal Measure Point

