




POWER FLOW



POWER ON SEQUENCE




Frequency Flow



Pink number is the GND diode resistance (without any part on MB)multimeter type DH-1240

Voltage Measure Point

multi meter “VΩmA” port touch here



Signal Measure Point

