




A55-C PLUS

R1.02





POWER FLOW

NOTE:




POWER ON SEQUENCE





FCH Power Sequence (S5-to-S0-to-S5)


Frequency Flow



Pink number is the GND diode resistance (without any part on MB)multimeter type DH-1240

Voltage Measure Point

multi meter "VΩmA" port touch here



Signal Measure Point

