


# RAMPAGE IV EXTREME Repair Guide


11/10/2011

Leilei52\_Chen


CSC-GRMA




# POWER FLOW



# POWER ON SEQUENCE



# Frequency FLOW






# Voltage Measure Point

multi meter " $V\Omega$  mA" port touch here

Pink number is Diode resistance to GND(without any part on MB)multimeter type DH-1240





# Signal Measure Point

