

# SERVICE MANUAL

W130EV / W130EW

*notebook*





**Notebook Computer**  
**W130EV / W130EW**  
**Service Manual**

## Notice

The company reserves the right to revise this publication or to change its contents without notice. Information contained herein is for reference only and does not constitute a commitment on the part of the manufacturer or any subsequent vendor. They assume no responsibility or liability for any errors or inaccuracies that may appear in this publication nor are they in anyway responsible for any loss or damage resulting from the use (or misuse) of this publication.

This publication and any accompanying software may not, in whole or in part, be reproduced, translated, transmitted or reduced to any machine readable form without prior consent from the vendor, manufacturer or creators of this publication, except for copies kept by the user for backup purposes.

Brand and product names mentioned in this publication may or may not be copyrights and/or registered trademarks of their respective companies. They are mentioned for identification purposes only and are not intended as an endorsement of that product or its manufacturer.

Version 1.0  
June 2012

## Trademarks

**Intel, Pentium and Intel Core** are trademarks of Intel Corporation.

**Windows®** is a registered trademark of Microsoft Corporation.

Other brand and product names are trademarks and /or registered trademarks of their respective companies.

## About this Manual

This manual is intended for service personnel who have completed sufficient training to undertake the maintenance and inspection of personal computers.

It is organized to allow you to look up basic information for servicing and/or upgrading components of the **W130EV** / **W130EW** series notebook PC.

The following information is included:

Chapter 1, Introduction, provides general information about the location of system elements and their specifications.  
Chapter 2, Disassembly, provides step-by-step instructions for disassembling parts and subsystems and how to upgrade elements of the system.

Appendix A, Part Lists

Appendix B, Schematic Diagrams

Appendix C, Updating the FLASH ROM BIOS

## Preface

---

### IMPORTANT SAFETY INSTRUCTIONS

Follow basic safety precautions, including those listed below, to reduce the risk of fire, electric shock and injury to persons when using any electrical equipment:

1. Do not use this product near water, for example near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electrical shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
5. This product is intended to be supplied by a Listed Power Unit with an AC Input of 100 - 240V, 50 - 60Hz, DC Output of 19V, 3.42A or 18.5V, 3.5A (65W) minimum AC/DC Adapter.

### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.


## Instructions for Care and Operation

The notebook computer is quite rugged, but it can be damaged. To prevent this, follow these suggestions:


1. **Don't drop it, or expose it to shock.** If the computer falls, the case and the components could be damaged.



2. **Keep it dry, and don't overheat it.** Keep the computer and power supply away from any kind of heating element. This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.




3. **Follow the proper working procedures for the computer.** Shut the computer down properly and don't forget to save your work. Remember to periodically save your data as data may be lost if the battery is depleted.



## Preface


4. **Avoid interference.** Keep the computer away from high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage your data.
5. **Take care when using peripheral devices.**



## Power Safety

The computer has specific power requirements:

- Only use a power adapter approved for use with this computer.
- Your AC adapter may be designed for international travel but it still requires a steady, uninterrupted power supply. If you are unsure of your local power specifications, consult your service representative or local power company.
- The power adapter may have either a 2-prong or a 3-prong grounded plug. The third prong is an important safety feature; do not defeat its purpose. If you do not have access to a compatible outlet, have a qualified electrician install one.
- When you want to unplug the power cord, be sure to disconnect it by the plug head, not by its wire.
- Make sure the socket and any extension cord(s) you use can support the total current load of all the connected devices.
- Before cleaning the computer, make sure it is disconnected from any external power supplies.



### Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.



## Battery Precautions

- Only use batteries designed for this computer. The wrong battery type may explode, leak or damage the computer.
- Do not continue to use a battery that has been dropped, or that appears damaged (e.g. bent or twisted) in any way. Even if the computer continues to work with a damaged battery in place, it may cause circuit damage, which may possibly result in fire.
- Recharge the batteries using the notebook's system. Incorrect recharging may make the battery explode.
- Do not try to repair a battery pack. Refer any battery pack repair or replacement to your service representative or qualified service personnel.
- Keep children away from, and promptly dispose of a damaged battery. Always dispose of batteries carefully. Batteries may explode or leak if exposed to fire, or improperly handled or discarded.
- Keep the battery away from metal appliances.
- Affix tape to the battery contacts before disposing of the battery.
- Do not touch the battery contacts with your hands or metal objects.

## Battery Guidelines

The following can also apply to any backup batteries you may have.

- If you do not use the battery for an extended period, then remove the battery from the computer for storage.
- Before removing the battery for storage charge it to 60% - 70%.
- Check stored batteries at least every 3 months and charge them to 60% - 70%.




### Battery Disposal

The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal.

### Caution

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used battery according to the manufacturer's instructions.

### Battery Level

Click the battery icon  in the taskbar to see the current battery level and charge status. A battery that drops below a level of 10% will not allow the computer to boot up. Make sure that any battery that drops below 10% is recharged within one week.

## Related Documents

You may also need to consult the following manual for additional information:


### User's Manual on CD/DVD

This describes the notebook PC's features and the procedures for operating the computer and its ROM-based setup program. It also describes the installation and operation of the utility programs provided with the notebook PC.

## System Startup

1. Remove all packing materials.
2. Place the computer on a stable surface.
3. Insert the battery and make sure it is locked in position.
4. Securely attach any peripherals you want to use with the computer (e.g. keyboard and mouse) to their ports.
5. Attach the AC/DC adapter to the DC-In jack at the left of the computer, then plug the AC power cord into an outlet, and connect the AC power cord to the AC/DC adapter.
6. Use one hand to raise the lid/LCD to a comfortable viewing angle (do not exceed 120 degrees); use the other hand (as illustrated in Figure 1) to support the base of the computer (**Note: Never** lift the computer by the lid/LCD).
7. Press the power button to turn the computer "on".

*Figure 1*  
Opening the Lid/LCD/  
Computer with AC/DC  
Adapter Plugged-In



## What to do if you Spill Liquid on the Computer

The keyboard incorporates a drainage system that minimizes the chances of liquid spillages on the keyboard penetrating the inside components of the computer. Liquid spilled on the computer is drained towards the right side of the computer. There is no guarantee that all water can be prevented from entering the computer, and damage resulting from spillages is not covered in the warranty. However if you follow the steps outlined here you should be able to prevent water from entering the sensitive parts of the computer and causing damage.

1. If you spill liquid on the computer immediately save any data required and then shut the computer down and disconnect the AC/DC adapter.
2. Carefully **lift the computer up and tilt it to a 90 degree angle towards the right side** (i.e. that right side of the computer should be at the bottom to allow **the water to drain away from the right side** and not the left).
3. Move the computer to a dry place and wipe any liquid off the keyboard and bottom of the computer using a clean, soft, dry cloth.
4. Remove the battery.
5. Leave the computer resting on its right side (while placed on a clean, soft, dry cloth) to dry out for about three hours.
6. Contact your service center to have the computer examined for any problems, **but do not attempt to turn the computer back on again** until after it has been examined.



*Figure 2 - Drain any Liquid to the Right Side and Rest the Computer on the Right Side to Dry*



### Warranty Warning

Note that the keyboard drainage system is designed to help prevent and minimize damage from liquid spillages on the computer keyboard. However damage resulting from spillages is not covered in the warranty.



# Contents

## Introduction .....1-1

Overview .....	1-1
Specifications .....	1-2
External Locator - Top View with LCD Panel Open .....	1-4
External Locator - Front & Right Side Views .....	1-5
External Locator - Left Side & Rear View .....	1-6
External Locator - Bottom View .....	1-7
Mainboard Overview - Top (Key Parts) .....	1-8
Mainboard Overview - Bottom (Key Parts) .....	1-9
Mainboard Overview - Top (Connectors) .....	1-10
Mainboard Overview - Bottom (Connectors) .....	1-11

## Disassembly .....2-1

Overview .....	2-1
Maintenance Tools .....	2-2
Connections .....	2-2
Maintenance Precautions .....	2-3
Disassembly Steps .....	2-4
Removing the Battery .....	2-5
Removing and Installing the Hard Disk Drive .....	2-6
Removing the System Memory (RAM) .....	2-9
Removing and Installing a Processor .....	2-10
Removing the 3.75G Module .....	2-13
Removing the Wireless LAN Module .....	2-14
Removing the Keyboard .....	2-15

## Part Lists .....A-1

Part List Illustration Location .....	A-2
Top .....	A-3
Bottom .....	A-4
HDD .....	A-5

LCD .....	A-6
-----------	-----

## Schematic Diagrams.....B-1

System Block Diagram .....	B-2
Processor 1/7 .....	B-3
Processor 2/7 .....	B-4
Processor 3/7 .....	B-5
Processor 4/7 .....	B-6
Processor 5/7 .....	B-7
Processor 6/7 .....	B-8
Processor 7/7 .....	B-9
DDR3 SO-DIMM_0 .....	B-10
DDR3 SO-DIMM_1 .....	B-11
LVDS, INVERTER .....	B-12
HDMI .....	B-13
CRT .....	B-14
PCH 1/9 .....	B-15
PCH 2/9 .....	B-16
PCH 3/9 .....	B-17
PCH 4/9 .....	B-18
PCH 5/9 .....	B-19
PCH 6/9 .....	B-20
PCH 7/9 .....	B-21
PCH 8/9 .....	B-22
PCH 9/9 .....	B-23
NEW CARD, MINI PCIE .....	B-24
CCD, 3G .....	B-25
TPM, HDD, USB3.0 CONN + PWR .....	B-26
KBC-ITE IT8518 .....	B-27
LED, MDC .....	B-28
AUDIO CODEC VIA VT1802P .....	B-29

## Preface

POWER CON, FAN, TP, CLICK CON .....	B-30
DOCKING CONNECTOR, COM PORT .....	B-31
AUDIO CONN, ESATA+USB+CHR .....	B-32
CARD READER JMC389 .....	B-33
LAN (INTEL LAN82579) .....	B-34
INTEL LAN 82579LM .....	B-35
5VS, 3VS, 1.5VS CPU .....	B-36
Power 1.5V/0.75V,1.8VS .....	B-37
VDD3, VDD5 .....	B-38
POWER 1.05V LAN_M .....	B-39
POWER 0.85VS .....	B-40
Power V-CORE 1 .....	B-41
Power V-CORE 2 .....	B-42
CHARGE, DC IN .....	B-43
CLICK BOARD / FG .....	B-44
AUDIO BOARD/ USB, HP, MIC .....	B-45
POWER SWITCH .....	B-46
DEBUG BOARD .....	B-47
Power Sequence .....	B-48

## Updating the FLASH ROM BIOS..... C-1


Download the BIOS .....	C-1
Unzip the downloaded files to a bootable CD/DVD/ or	
USB Flash drive .....	C-1
Set the computer to boot from the external drive .....	C-1
Use the flash tools to update the BIOS .....	C-2
Restart the computer (booting from the HDD) .....	C-2

# Chapter 1: Introduction

## Overview

This manual covers the information you need to service or upgrade the **W130EV / W130EW** series notebook computer. Information about operating the computer (e.g. getting started, and the *Setup* utility) is in the *User's Manual*. Information about drivers (e.g. VGA & audio) is also found in the *User's Manual*. The manual is shipped with the computer.

Operating systems (e.g. *Window 7*, etc.) have their own manuals as do application softwares (e.g. word processing and database programs). If you have questions about those programs, you should consult those manuals.

The **W130EV / W130EW** series notebook is designed to be upgradeable. See [Disassembly on page 2 - 1](#) for a detailed description of the upgrade procedures for each specific component. Please take note of the warning and safety information indicated by the “” symbol.

The balance of this chapter reviews the computer's technical specifications and features.

## Introduction

## Specifications



### Latest Specification Information

The specifications listed here are correct at the time of sending them to the press. Certain items (particularly processor types/speeds) may be changed, delayed or updated due to the manufacturer's release schedule. Check with your service center for more details.



### CPU

The CPU is not a user serviceable part. Accessing the CPU in any way may violate your warranty.

### Processor Options

#### W130EW:

##### Intel® Core™ i7 Processor

##### **i7-3612QM (2.10GHz)**

6MB L3 Cache, **22nm**, DDR3-1600MHz, TDP 35W

##### **i7-3520M (2.90GHz)**

4MB L3 Cache, **22nm**, DDR3-1600MHz, TDP 35W

##### Intel® Core™ i5 Processor

##### **i5-3360M (2.80GHz), i5-3320M (2.60GHz), i5-3210M (2.50GHz)**

3MB L3 Cache, **22nm**, DDR3-1600MHz, TDP 35W

##### Intel® Core™ i3 Processor

##### **i3-3110M (2.40GHz)**

3MB L3 Cache, **22nm**, DDR3-1600MHz, TDP 35W

##### Intel® Core™ i7 Processor

##### **i7-2640M (2.80GHz)**

4MB L3 Cache, **32nm**, DDR3-1333MHz, TDP 35W

##### Intel® Core™ i5 Processor

##### **i5-2540M (2.60GHz), i5-2520M (2.50GHz), i5-2450M (2.50GHz), i5-2430M (2.40GHz)**

3MB L3 Cache, **32nm**, DDR3-1333MHz, TDP 35W

##### Intel® Core™ i3 Processor

##### **i3-2370M (2.40GHz), i3-2350M (2.30GHz),**

3MB L3 Cache, **32nm**, DDR3-1333MHz, TDP 35W

##### Intel® Pentium™ Processor

##### **B980 (2.40GHz), B970 (2.30GHz), B960 (2.20GHz), B950 (2.10GHz)**

2MB L3 Cache, **32nm**, DDR3-1333MHz, TDP 35W

#### W130EV:

##### Intel® Core™ i7 Processor

##### **i7-3520M (2.90GHz)**

4MB L3 Cache, **22nm**, DDR3-1600MHz, TDP 35W

##### Intel® Core™ i5 Processor

##### **i5-3360M (2.80GHz), i5-3320M (2.60GHz)**

3MB L3 Cache, **22nm**, DDR3-1600MHz, TDP 35W

### LCD

13.3" (33.78cm) HD LCD

### BIOS

AMI BIOS (One 64Mb SPI Flash ROM)

### Core Logic

#### W130EW:

Intel® HM77 Chipset

#### W130EV:

Intel® QM77 Chipset

### Memory

Two 204 Pin SO-DIMM Sockets Supporting **DDR3 1333/1600MHz** Memory

Memory Expandable up to **8GB**

(The real memory operating frequency depends on the FSB of the processor.)

### Video Adapter (W130EW)

#### Intel Integrated GPU

*(GPU is Dependent on Processor)*

#### Intel® HD Graphics

Dynamic Frequency (Intel Dynamic Video Memory Technology for up to **1.7GB**)

Microsoft DirectX®10 Compatible

#### Intel® HD Graphics 3000

Dynamic Frequency (Intel Dynamic Video Memory Technology for up to **1.7GB**)

Microsoft DirectX®10 Compatible

#### Intel® HD Graphics 4000

Dynamic Frequency (Intel Dynamic Video Memory Technology for up to **1.7GB**)

Microsoft DirectX®11 Compatible

### Video Adapter (W130EV)

#### Intel® HD Graphics 4000

Dynamic Frequency (Intel Dynamic Video Memory Technology for up to **1.7GB**)

Microsoft DirectX®11 Compatible



**Storage**

One Changeable 2.5" 9.5 mm (h) SATA (Serial) HDD  
Anti-Shock System

**Audio**

High Definition Audio Compliant Interface  
2 \* Built-In Speakers  
Built-In Microphone

**Security**

BIOS Password  
Security (Kensington® Type) Lock Slot  
Fingerprint Reader  
TPM v1.2  
Intel vPro (**W130EV only**)

**Keyboard**

Isolated A4 Size Keyboard with Anti-Spray Support

**Pointing Device**

Built-in Touchpad (scrolling key functionality integrated)

**Interface**

One Powered USB 2.0 Port  
Two USB 3.0 Ports  
One eSATA/USB 2.0 Combo Port  
One HDMI-Out Port  
One Headphone-Out Jack  
One Microphone-In Jack  
One RJ-45 LAN Jack  
One External Monitor Port  
One ExpressCard/34(54) Slot  
One DC-in Jack  
(**Factory Option**) One Docking Port

**Communication**

Built-In Gigabit Ethernet LAN  
(**Factory Option**) 1.3M Pixels/2M Pixels (HD) PC Camera Module  
(**Factory Option**) 3G Module (UMTS/HSPA or UMTS/HSPA+)

**WLAN/ Bluetooth Half Mini-Card Modules:****W130EW:**

(**Factory Option**) Intel® Centrino® Wireless-N 2230 Wireless LAN (**802.11b/g/n**) + Bluetooth **4.0**  
(**Factory Option**) Intel® Centrino® Wireless-N 135 Wireless LAN (**802.11b/g/n**) + Bluetooth **4.0**  
(**Factory Option**) Third-Party Wireless LAN (**802.11b/g/n**) + Bluetooth **4.0**  
(**Factory Option**) Third-Party Wireless LAN (**802.11b/g/n**)

**W130EV:**

(**Factory Option**) Intel® Centrino® Advanced-N 6235 Wireless LAN (**802.11a/g/n**) + Bluetooth **4.0**  
(**Factory Option**) Intel® Centrino® Advanced-N 6205 Wireless LAN (**802.11a/g/n**)

**Card Reader**

Embedded Multi-in-1 Push-Push Card Reader  
MMC (MultiMedia Card) / RS MMC  
SD (Secure Digital) / Mini SD / SDHC/ SDXC  
MS (Memory Stick) / MS Pro / MS Duo

**Mini Card Slots**

Slot 1 for **WLAN** Module or **WLAN and Bluetooth** Combo Module  
(**Factory Option**) Slot 2 for **3G** Module

**Environmental Spec****Temperature**

Operating: 5°C - 35°C  
Non-Operating: -20°C - 60°C

**Relative Humidity**

Operating: 20% - 80%  
Non-Operating: 10% - 90%

**Power**

Full Range AC/DC Adapter  
AC Input: 100 - 240V, 50 - 60Hz  
DC Output: 19V, 3.42A or 18.5V, 3.5A (**65W**)

6 Cell Smart Lithium-Ion Battery Pack, 62.16WH

**Dimensions & Weight**

330mm (w) \* 225mm (d) \* 24.5 - 32mm (h)  
1.78kg with 62.16WH Battery

## Introduction

*Figure 1*  
**Top View**

1. PC Camera  
(Optional)
2. LCD
3. Power Button
4. Keyboard
5. Built-In  
Microphone
6. Touchpad &  
Buttons
7. Fingerprint Reader
8. LED Status  
Indicators

## External Locator - Top View with LCD Panel Open



## External Locator - Front & Right Side Views

FRONT VIEW



*Figure 2*  
**Front View**

1. LED Power Indicator
2. WLAN Switch

RIGHT SIDE VIEW



*Figure 3*  
**Right Side View**

1. Microphone-In Jack
2. Headphone-Out Jack
3. USB 2.0 Port
4. Vent
5. Security Lock Slot

## Introduction

### External Locator - Left Side & Rear View

*Figure 4*  
**Left Side View**

1. DC-In Jack
2. External Monitor Port
3. RJ-45 LAN Jack
4. e-SATA Port/USB 2.0 Combo Port
5. HDMI-Out Port
6. 2 \* USB 3.0 Ports
7. ExpressCard/54(34) Slot
8. Multi-in-1 Card Reader

LEFT SIDE VIEW




*Figure 5*  
**Rear View**

1. Battery

REAR VIEW



## External Locator - Bottom View



*Figure 6*  
**Bottom View**

1. Battery
2. Docking Port
3. Vent
4. Component Bay Cover
5. Drainage Outlet
6. Speakers



### Overheating

To prevent your computer from overheating, make sure nothing blocks any vent while the computer is in use.




## Introduction


*Figure 7*  
**Mainboard Top  
Key Parts**

1. PI3L720ZHE
2. TUSB7320
3. ITE IT870SE
4. SIMLOCK

## Mainboard Overview - Top (Key Parts)



## Mainboard Overview - Bottom (Key Parts)



*Figure 8*  
**Mainboard Bottom  
Key Parts**

1. CPU Socket (no CPU installed)
2. Audio Codec VT1802P
3. ITE IT8518E
4. Memory Slots DDR3 SO-DIMM
5. Platform Controller Hub
6. LAN 82579
7. Card Reader JMB369
8. CMOS Battery
9. Mini-Card Connector (3G Module)
10. Mini-Card Connector (WLAN Module)
11. Docking Station Connector




## Introduction

*Figure 9*  
**Mainboard Top  
Connectors**


1. e-SATA Port/USB 2.0 Combo Port
2. HDMI-Out Port
3. USB Port 3.0
4. Audio Board Connector
5. Keyboard Cable Connector

## Mainboard Overview - Top (Connectors)





## Mainboard Overview - Bottom (Connectors)



*Figure 10*  
**Mainboard Bottom  
Connectors**

1. Power Cable Connector
2. Fan Cable Connector
3. CCD Cable Connector
4. HDD Connector
5. TouchPad Cable Connector
6. Microphone Cable Connector
7. Multi-in-1 Card Reader
8. Speaker Cable Connector
9. RJ-45 LAN Jack
10. External Monitor Port
11. DC-In Jack
12. LVDS Cable Connector
13. Battery Connector




# Chapter 2: Disassembly

## Overview

This chapter provides step-by-step instructions for disassembling the *W130EV / W130EW* series notebook's parts and subsystems. When it comes to reassembly, reverse the procedures (unless otherwise indicated).


We suggest you completely review any procedure before you take the computer apart.

Procedures such as upgrading/replacing the RAM, optical device and hard disk are included in the User's Manual but are repeated here for your convenience.

To make the disassembly process easier each section may have a box in the page margin. Information contained under the figure # will give a synopsis of the sequence of procedures involved in the disassembly procedure. A box with a  lists the relevant parts you will have after the disassembly process is complete. **Note:** The parts listed will be for the disassembly procedure listed ONLY, and not any previous disassembly step(s) required. Refer to the part list for the previous disassembly procedure. The amount of screws you should be left with will be listed here also.

A box with a  will also provide any possible helpful information. A box with a  contains warnings.

An example of these types of boxes are shown in the sidebar.



## Disassembly

---

**NOTE:** All disassembly procedures assume that the system is turned **OFF**, and disconnected from any power supply (the battery is removed too).

### Maintenance Tools

The following tools are recommended when working on the notebook PC:

- M3 Philips-head screwdriver
- M2.5 Philips-head screwdriver (magnetized)
- M2 Philips-head screwdriver
- Small flat-head screwdriver
- Pair of needle-nose pliers
- Anti-static wrist-strap

### Connections

Connections within the computer are one of four types:

Locking collar sockets for ribbon connectors	To release these connectors, use a small flat-head screwdriver to gently pry the locking collar away from its base. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Pressure sockets for multi-wire connectors	To release this connector type, grasp it at its head and gently rock it from side to side as you pull it out. Do not pull on the wires themselves. When replacing the connection, do not try to force it. The socket only fits one way.
Pressure sockets for ribbon connectors	To release these connectors, use a small pair of needle-nose pliers to gently lift the connector away from its socket. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Board-to-board or multi-pin sockets	To separate the boards, gently rock them from side to side as you pull them apart. If the connection is very tight, use a small flat-head screwdriver - use just enough force to start.

## Maintenance Precautions

The following precautions are a reminder. To avoid personal injury or damage to the computer while performing a removal and/or replacement job, take the following precautions:

1. **Don't drop it.** Perform your repairs and/or upgrades on a stable surface. If the computer falls, the case and other components could be damaged.
2. **Don't overheat it.** Note the proximity of any heating elements. Keep the computer out of direct sunlight.
3. **Avoid interference.** Note the proximity of any high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage components and/or data. You should also monitor the position of magnetized tools (i.e. screwdrivers).
4. **Keep it dry.** This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.
5. **Be careful with power.** Avoid accidental shocks, discharges or explosions.
  - Before removing or servicing any part from the computer, turn the computer off and detach any power supplies.
  - When you want to unplug the power cord or any cable/wire, be sure to disconnect it by the plug head. Do not pull on the wire.
6. **Peripherals** – Turn off and detach any peripherals.
7. **Beware of static discharge.** ICs, such as the CPU and main support chips, are vulnerable to static electricity. Before handling any part in the computer, discharge any static electricity inside the computer. When handling a printed circuit board, do not use gloves or other materials which allow static electricity buildup. We suggest that you use an anti-static wrist strap instead.
8. **Beware of corrosion.** As you perform your job, avoid touching any connector leads. Even the cleanest hands produce oils which can attract corrosive elements.
9. **Keep your work environment clean.** Tobacco smoke, dust or other air-born particulate matter is often attracted to charged surfaces, reducing performance.
10. **Keep track of the components.** When removing or replacing any part, be careful not to leave small parts, such as screws, loose inside the computer.

## Cleaning

Do not apply cleaner directly to the computer, use a soft clean cloth.

Do not use volatile (petroleum distillates) or abrasive cleaners on any part of the computer.



### Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

## Disassembly Steps

The following table lists the disassembly steps, and on which page to find the related information. **PLEASE PERFORM THE DISASSEMBLY STEPS IN THE ORDER INDICATED.**

### To remove the Battery:

1. Remove the battery *page 2 - 5*

### To remove the HDD:

1. Remove the battery *page 2 - 5*
2. Remove the HDD *page 2 - 6*

### To remove the System Memory:

1. Remove the battery *page 2 - 5*
2. Remove the system memory *page 2 - 9*

### To remove and install a Processor:

1. Remove the battery *page 2 - 5*
2. Remove the processor *page 2 - 10*
3. Install the processor *page 2 - 12*

### To remove the 3.75G Module:

1. Remove the battery *page 2 - 5*
2. Remove the 3.75G module *page 2 - 13*

### To remove the Wireless LAN Module:


1. Remove the battery *page 2 - 5*
2. Remove the WLAN module *page 2 - 14*

### To remove the Keyboard:

1. Remove the battery *page 2 - 5*
2. Remove the keyboard *page 2 - 15*


## Removing the Battery

1. Turn the computer **off**, and turn it over.
2. Slide the latch **1** in the direction of the arrow (*Figure 1a*).
3. Slide the latch **2** in the direction of the arrow, and hold it in place (*Figure 1a*).
4. Slide the battery **3** in the direction of the arrow **4** (*Figure 1b*).



*Figure 1*  
**Battery Removal**

- a. Slide the latch and hold it in place.
- b. Slide the battery in the direction of the arrow.





## Disassembly

*Figure 2*  
**HDD Assembly  
Removal**

- Slide the latches and latch ② hold it in place.
- Remove the component bay cover.


## Removing and Installing the Hard Disk Drive

### Hdd Removal Procedure

The hard disk drive can be taken out to accommodate other 2.5" serial (SATA) hard disk drives with a height of 9.5mm (h). Follow your operating system's installation instructions, and install all necessary drivers and utilities (as outlined in **Chapter 4 of the User's Manual**) when setting up a new hard disk.

### Hard Disk Upgrade Process

- Turn **off** the computer, and remove the battery ([page 2 - 5](#)).
- Slide the latch ① in the direction of the arrow and slide the latch ② in the direction of the arrow, and hold it in place and carefully slide the cover in the direction of the arrow ③ to align with the markers on the case ④.
- Lift the component bay cover ⑤ off the computer.
- When reinserting the cover align the markers on the case ④ and cover first, and then slide the cover until it clicks into place.



#### HDD System Warning

New HDD's are blank. Before you begin make sure:

You have backed up any data you want to keep from your old HDD.

You have all the CD-ROMs and FDDs required to install your operating system and programs.






If you have access to the internet, download the latest application and hardware driver updates for the operating system you plan to install. Copy these to a removable medium.



5. Raise the plastic tab ⑥.
6. Slide the hard disk assembly in the direction of arrow ⑦ until you can see the (gold colored) HDD connector ⑧.
7. When the connector can be viewed, lift the assembly up in the direction of arrow ⑨ remove the HDD assembly from the bay.
8. Remove the screws ⑩ & ⑪ and the mylar cover ⑫ from the hard disk ⑬ (Figure 3e)..

*Figure 3*  
**HDD Assembly Removal (cont'd.)**

- c. Raise the plastic tab.
- d. Grip the tab and slide the HDD assembly in the direction of the arrow.
- e. Lift the HDD assembly out of the bay.
- f. Remove the screws and mylar cover.



9. HDD Assembly  
12. Mylar Cover  
13. HDD
- 2 Screws

## Disassembly

*Figure 4*  
**HDD Installation**

- Insert the HDD directly down into the bay vertically.
- Press and slide the HDD assembly at the area illustrated **2**
- Press down on the rubber case



### Hard Disk Handling


Do not press down on the center off the hard disk as this area houses the hard disk drive motor.



1. HDD Assembly

### Reinserting the HDD

- To reinsert the HDD assembly **1** hold it carefully at the four corners between your thumb and forefinger and Insert the HDD directly down into the bay vertically (*Figure 1a*).
- Press and slide the HDD assembly at the area illustrated **2** (do not press on the center area - see sidebar) the direction of arrows to make sure the HDD fits securely into the connector.
- Press down on the rubber case **3** to ensure the assembly is properly seated before replacing the cover and screws.
- Replace the component bay cover (*page 2 - 6*).



## Removing the System Memory (RAM)

The computer has two memory sockets for 204 pin Small Outline Dual In-line Memory Modules (SO-DIMM) supporting DDRIII (DDR3) Up to 1333 MHz. The main memory can be expanded up to 8GB. The SO-DIMM modules supported are 1024MB and 2048MB **DDRIII** Modules. The total memory size is automatically detected by the POST routine once you turn on your computer.

### Memory Upgrade Process

1. Turn **off** the computer, turn it over and remove the battery ([page 2 - 5](#)) and remove the component bay cover ([page 2 - 6](#)).
2. The RAM modules will be visible at point **1** on the mainboard.
3. Gently pull the two release latches (**2** & **3**) on the sides of the memory socket in the direction indicated by the arrows ([Figure 5b](#)). The RAM module **4** will pop-up ([Figure 5c](#)), and you can then remove it.
4. Pull the latches to release the second module if necessary.
5. Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.
6. The module will only fit one way as defined by its pin alignment. Make sure the module is seated as far into the slot as it will go. **DO NOT FORCE IT**; it should fit without much pressure.
7. Press the module in and down towards the mainboard until the slot levers click into place to secure the module.
8. Replace the component bay cover (see [page 2 - 6](#)).
9. Restart the computer to allow the BIOS to register the new memory configuration as it starts up.

*Figure 5*  
**RAM Module Removal**

- a. The RAM modules will be visible at point **1** on the mainboard.
- b. Pull the release latches.
- c. Remove the module.




#### Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.



4. RAM Modules





## Disassembly

Figure 6


## Processor Removal

- a. The CPU heat sink will be visible at point **A**.
- b. Remove the screws from the CPU heatsink.
- c. Grip the heat sink tab and carefully lift the heat sink up and off the computer.

## Removing and Installing a Processor


## Processor Removal Procedure

1. Turn **off** the computer, turn it over, and remove the battery ([page 2 - 5](#)) and the component bay cover ([page 2 - 9](#)).
2. The CPU heat sink will be visible at point **A** ([Figure 6a](#)).
3. Loosen the CPU heat sink screws in the order **3**, **2** & **1** (the reverse order as indicated on the label [Figure 6b](#)).
4. Grip the heat sink tab **4** and carefully raise the heat sink **5** up to an angle of around 30° and lift it up off the computer ([Figure 6c](#)).



5. Heat Sink


- 3 Screws

5. Turn the release latch **6** towards the unlock symbol  to release the CPU (**Figure 7d**).
6. Carefully (it may be hot) lift the CPU **7** up and out of the socket (**Figure 7e**).
7. Reverse the process to install a new CPU.
8. When re-inserting the CPU, pay careful attention to the pin alignment, it will fit only one way (DO NOT FORCE IT!).


*Figure 7*  
**Processor Removal (cont'd)**

- d. Turn the release latch to unlock the CPU.
- e. Lift the CPU out of the socket.

c.




Unlock



Lock

d.



### Caution

The heat sink, and CPU area in general, contains parts which are subject to high temperatures. Allow the area time to cool before removing these parts.




7. CPU


## Disassembly

*Figure 8*  
**Processor Installation**

- Insert the CPU.
- Turn the release latch towards the lock symbol.
- Insert the heat sink.
- Tighten the screws.

### Processor Installation Procedure

- Insert the CPU **A** (*Figure 8a*), pay careful attention to the pin alignment, it will fit only one way (DO NOT FORCE IT!), and turn the release latch **B** towards the lock symbol  (*Figure 8b*).
- Insert the heat sink **D** at an angle of around 30° as indicated in *Figure 8c*.
- Tighten the CPU heat sink screws in the order **1**, **2** & **3** (the order as indicated on the label and *Figure 8d*).
- Replace the component bay cover.





**Note:**  
Tighten the screws  
in the order as indi-  
cated on the label.

- A. CPU  
D. Heat Sink
- 3 Screws



## Removing the 3.75G Module

1. Turn **off** the computer, turn it over, and remove the battery ([page 2 - 5](#)) and the component bay cover ([page 2 - 9](#)).
2. The 3.75G module will be visible at point **1** on the mainboard ([Figure 9a](#)).
3. Carefully disconnect the cable **2**, and then remove the screw **3** ([Figure 9b](#)).
4. The 3.75G module **4** will pop-up, and you can remove it from the computer ([Figure 9c](#)).



*Figure 9*  
**3G Module Removal**

- Locate the 3.75G module.
- Disconnect the cable and remove the screw.
- The module will pop-up and remove the 3.75G module.

Note: Make sure you reconnect the antenna cable to socket.



4. 3.75G Module

- 1 Screw

## Disassembly

*Figure 10*  
**Wireless LAN  
Module Removal**

- Locate the WLAN Module.
- Disconnect the cable and remove the screw.
- The WLAN module will pop up.

Note: Make sure you reconnect the antenna cable to the “1 + 2” socket (*Figure 10b*).






4. Wireless LAN Module

- 2 Screws

## Removing the Wireless LAN Module

- Turn **off** the computer, turn it over, and remove the battery (*page 2 - 5*) and the component bay cover (*page 2 - 9*).
- The Wireless LAN module will be visible at point **1** on the mainboard (*Figure 10a*).
- Carefully disconnect the cables **2** - **3**, and then remove the screw **4** (*Figure 10b*).
- The Wireless LAN module **4** (*Figure 10c*) will pop-up, and you can remove it from the computer.






## Removing the Keyboard

1. Turn **off** the computer remove the battery ([page 2 - 5](#)), and the component bay cover ([page 2 - 9](#)).
2. Remove screws **1** - **4** from the bottom of the computer.
3. Carefully raise the keyboard up, being careful not to bend the keyboard ribbon cable **5**. and remove screws **6** - **9** from the plate.
4. Remove the plate **10**.
5. Disconnect the keyboard ribbon cable **11** from the locking collar socket **12** ([Figure 11c](#))
6. Carefully lift up the keyboard **13** off the computer.


a.



d.




b.



c.



e.



*Figure 11*  
**Keyboard Removal**

- a. Remove screws from the bottom of the computer.
- b. Remove screws from the plate.
- c. Remove the plate.
- d. Carefully lift the keyboard up and disconnect the keyboard ribbon cable from the locking collar socket.
- e. Remove the keyboard.



### Re-Inserting the Keyboard

When re-inserting the keyboard firstly align the **four** keyboard tabs at the bottom ([Figure 11e](#)) at the bottom of the keyboard with the slots in the case.



10. Plate for keyboard  
13. Keyboard

- 8 Screws



---

# Appendix A:Part Lists

This appendix breaks down the **W130EV / W130EW** series notebook's construction into a series of illustrations. The component part numbers are indicated in the tables opposite the drawings.

**Note:** This section indicates the *manufacturer's* part numbers. Your organization may use a different system, so be sure to cross-check any relevant documentation.

**Note:** Some assemblies may have parts in common (especially screws). However, the part lists DO NOT indicate the total number of duplicated parts used.

**Note:** Be sure to check any update notices. The parts shown in these illustrations are appropriate for the system at the time of publication. Over the product life, some parts may be improved or re-configured, resulting in *new* part numbers.

---

## Part List Illustration Location

The following table indicates where to find the appropriate part list illustration.


*Table A - 1*  
**Part List Illustration  
Location**

Part	
Top	<i>page A - 3</i>
Bottom	<i>page A - 4</i>
HDD	<i>page A - 5</i>
LCD	<i>page A - 6</i>



# Bottom

Figure A - 2  
Bottom



ITEM	PART NAME	PART NO	REMARK
1	SCREW M2.5*6L K BZ ICT NY	6-35-82125-6RA	
2	MAIN BOARD V28 (W/3G W/MDC) W130EW	6-77-W13W0-D02	
2	MAIN BOARD V28 (W/3G W/D MDC) W130EW	6-77-W13W0-D02-1	
2	MAIN BOARD V28 (W/3G W/MDC) W130EV	6-77-W13E0-D02	
2	MAIN BOARD V28 (W/3G W/D MDC) W130EV	6-77-W13E0-D02-1	
3	BATTERY 3V 210MA CR2032 (MITSUBISHI)	6-23-62015-607	
4	DUMMY PC CARD PC+ABS INIZOR (GEM)	6-42-T12R3-011-2	
5	CPU CABLE FOR MB TO CPU (W/3G W/MDC) W130EW	6-88-W345F-9400	(OPTION)
5	CPU CABLE FOR MB TO CPU (W/3G W/D MDC) W130EW	6-88-W25H2-9400	(OPTION)
5	CPU CABLE FOR MB TO CPU (W/3G W/MDC) W130EV	6-88-P17EF-4200	(OPTION)
5	CPU CABLE FOR MB TO CPU (W/3G W/D MDC) W130EV	6-88-P17OF-4210	(OPTION)
5	CPU CABLE FOR MB TO CPU (W/3G W/MDC) W130EV	6-88-W345F-8700	(OPTION)
5	CPU CABLE FOR MB TO CPU (W/3G W/D MDC) W130EV	6-88-W11OF-4200	(OPTION)
5	CPU CABLE FOR MB TO CPU (W/3G W/MDC) W130EV	6-88-P1702-4200	(OPTION)
6	SCREW M2X0.5 KI NI ICT NY (00-44.5DT-04)	6-35-B1120-3RE	
7	WCDMA ERICSSON F320T HSPA FULL MINI-CARD USB	6-88-W24HW-2410	(OPTION)
8	WCDMA ERICSSON F320T HSPA FULL MINI-CARD USB	6-87-W130S-4D71	(OPTION)
9	TAPE MYLAR TRANSPARENT (0.05MM*0.05) P1803	6-40-P1803-020	
10	LED LENS SPONGE W130HU	6-47-W130S-010	
11	CPU SUPPORTER FOR HARMON RIVER SECC W150NM	6-33-W150S-011	
12	CPU HEATSINK MODULE W130HU	6-31-W130N-101	
13	CABLE L 47A04 20W 4.1 1.5MM PERFORMER-XX W130HU	6-23-5W130-0L0	
14	FTC CABLE FOR MB TO AUDIO BOARD 20PIN 08D	6-43-W15HS-010-1	
15	BOTTOM CASE HDD RUBBER (0.05MM) SILICONE W130HU	6-47-W130S-051	
16	AUDIO BOARD V2.0A W130HU	6-77-W1308-D02A	
17	CABLE R 45A04 20W 4.1 1.5MM PERFORMER-XX W130HU	6-23-5W130-0R1	
18	BOTTOM CASE MODULE W130HU	6-39-W1303-013	
19	FAN MODULE W150HNM	6-23-AV150-100	
20	W/HDD ASSY W130HU/W130HV	6-79-W130HUJ-010	
20	W/D HDD ASSY W130HU/W130HV	6-79-W130HUJ-020	
21	CPU COVER MODULE W130HU	6-42-W1308-102	
22	PRODUCT LABEL FOR W130EW	6-45-W130EW3-010	
22	PRODUCT LABEL FOR W130EV	6-45-W130EV3-010	
23	SCREW M2.5*4L F NI ICT NY	6-35-21125-4R0	
24	MYLAR (15*6*0.6T) FOR M77X	6-40-M7703-010	
25	RJ45 DUMMY RUBBER KE-56120U W130HU	6-47-W1303-011	

HDD





Figure A - 3  
HDD

LCD

Figure A - 4  
LCD



ITEM	PART NAME	PART NO.	REMARK
1	LCD FRONT COVER PROTECT FILM PET W830T	6-40-W83TT-011	
2	RUBBER GASKET FOR FRONT COVER SCREW W830T	6-47-W83TT-061	
3	FRONT COVER SCREW W830T	6-78-W83TT-001	
4	CCD MYLAR PC8010 W840T	6-40-W84TT-011	W/ CCD
5	W/D CCD MYLAR PC8010 W840T	6-40-W84TT-020	W/D CCD
6	LCD HINGE COVER L PC+ABS W130HU	6-42-W130T-020	
7	SCREW M2*3L I BK/Z ICT NY	6-35-C6120-3R0	
8	LCD HINGE COVER R PC+ABS W130HU	6-42-W130T-010	
9	SCREW M1.6*2L D=32 T=0.4 KI BZ ICT NY	6-35-B2116-2R0	
10	LCD 13.3" HD CHINESE LCD GLARE TYPE QLED 300M	6-50-G8136-DD1	
11	LCD 13.3" HD LG LP133WH2-TL12 GLARE TYPE	6-50-G8136-L00	
12	LCD 13.3" HD LG LP133WH2-TL12 GLARE TYPE	6-50-G8136-L00	
13	LCD 13.3" HD TOSHIBA L133DEPR100 GLARE TYPE	6-50-G8136-T00	
14	LCD 13.3" HD CHINESE LCD GLARE TYPE QLED 300M	6-50-G8136-DD0	
15	SCREW M2*3L KI NI ICT NY 130-445.01-040	6-35-B1120-3RE	
16	LCD BKT L SECC 0.5T W830T	6-33-W83TT-022	
17	LCD BKT R SECC 0.5T W830T	6-23-7W130-020	
18	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
19	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
20	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
21	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
22	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
23	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
24	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
25	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
26	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
27	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
28	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
29	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
30	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
31	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
32	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
33	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
34	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
35	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
36	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
37	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
38	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
39	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
40	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
41	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
42	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
43	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
44	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
45	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
46	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
47	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
48	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
49	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
50	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
51	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
52	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
53	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
54	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
55	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
56	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
57	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
58	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
59	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
60	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
61	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
62	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
63	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
64	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
65	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
66	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
67	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
68	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
69	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
70	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
71	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
72	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
73	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
74	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
75	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
76	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
77	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
78	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
79	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
80	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
81	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
82	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
83	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
84	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
85	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
86	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
87	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
88	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
89	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
90	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
91	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
92	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
93	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
94	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
95	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
96	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
97	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
98	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
99	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	
100	WIRE CABLE FOR CCD SP 494MM W130HU ONLY	6-88-W25CC-4900	



# Appendix B: Schematic Diagrams

This appendix has circuit diagrams of the *W130EV / W130EW* notebook's PCB's. The following table indicates where to find the appropriate schematic diagram.

Diagram - Page	Diagram - Page	Diagram - Page
<i>System Block Diagram - Page B - 2</i>	<i>PCH 5/9 - Page B - 19</i>	<i>5VS, 3VS, 1.5VS CPU - Page B - 36</i>
<i>Processor 1/7 - Page B - 3</i>	<i>PCH 6/9 - Page B - 20</i>	<i>Power 1.5V/0.75V, 1.8VS - Page B - 37</i>
<i>Processor 2/7 - Page B - 4</i>	<i>PCH 7/9 - Page B - 21</i>	<i>VDD3, VDD5 - Page B - 38</i>
<i>Processor 3/7 - Page B - 5</i>	<i>PCH 8/9 - Page B - 22</i>	<i>POWER 1.05V LAN_M - Page B - 39</i>
<i>Processor 4/7 - Page B - 6</i>	<i>PCH 9/9 - Page B - 23</i>	<i>POWER 0.85VS - Page B - 40</i>
<i>Processor 5/7 - Page B - 7</i>	<i>NEW CARD, MINI PCIE - Page B - 24</i>	<i>Power V-CORE 1 - Page B - 41</i>
<i>Processor 6/7 - Page B - 8</i>	<i>CCD, 3G - Page B - 25</i>	<i>Power V-CORE 2 - Page B - 42</i>
<i>Processor 7/7 - Page B - 9</i>	<i>TPM, HDD, USB3.0 CONN + PWR - Page B - 26</i>	<i>CHARGE, DC IN - Page B - 43</i>
<i>DDR3 SO-DIMM_0 - Page B - 10</i>	<i>KBC-ITE IT8518 - Page B - 27</i>	<i>CLICK BOARD / FG - Page B - 44</i>
<i>DDR3 SO-DIMM_1 - Page B - 11</i>	<i>LED, MDC - Page B - 28</i>	<i>AUDIO BOARD/ USB, HP, MIC - Page B - 45</i>
<i>LVDS, INVERTER - Page B - 12</i>	<i>AUDIO CODEC VIA VT1802P - Page B - 29</i>	<i>POWER SWITCH - Page B - 46</i>
<i>HDMI - Page B - 13</i>	<i>POWER CON, FAN, TP, CLICK CON - Page B - 30</i>	<i>DEBUG BOARD - Page B - 47</i>
<i>CRT - Page B - 14</i>	<i>DOCKING CONNECTOR, COM PORT - Page B - 31</i>	<i>Power Sequence - Page B - 48</i>
<i>PCH 1/9 - Page B - 15</i>	<i>AUDIO CONN, ESATA+USB+CHR - Page B - 32</i>	
<i>PCH 2/9 - Page B - 16</i>	<i>CARD READER JMC389 - Page B - 33</i>	
<i>PCH 3/9 - Page B - 17</i>	<i>LAN (INTEL LAN82579) - Page B - 34</i>	
<i>PCH 4/9 - Page B - 18</i>	<i>INTEL LAN 82579LM - Page B - 35</i>	


*Table B - 1*  
**SCHEMATIC  
DIAGRAMS**



## Version Note

The schematic diagrams in this chapter are based upon version 6-7P-W13E5-002. If your mainboard (or other boards) are a later version, please check with the Service Center for updated diagrams (if required).

**Sheet 1 of 47**  
**System Block**  
**Diagram**




## B.Schematic Diagrams

Sheet 2 of 47  
Processor 1/7






[illegible]

Processor 4/7


Sheet 5 of 47  
Processor 4/7

Ivy/Sandy Bridge Processor 4/7



**Processor 5/7 B - 7**

Sheet 6 of 47  
Processor 5/7




Processor 6/7

Ivy/Sandy Bridge Processor 6/7 ( GND )






CAD Note: 0 ohm resistor  
should be placed close  
to CPU

Sheet 7 of 47  
Processor 6/7





## Processor 7/7

Ivy/Sandy Bridge Processor 7/7  
( RESERVED )


[3,6,9,10,21,27,28,35,36] 1.5V  
[2,3,6,11,14,15,18,23,24,27,29,30,35,36,38,39] 3.3V



Sheet 8 of 47  
Processor 7/7

## DDR3 SO-DIMM\_0


## CHANGE TO STANDARD




## DDR3 SO-DIMM\_1

## SO-DIMM B

CHANGE TO STANDARD

Sheet 10 of 47  
DDR3 SO-DIMM\_1

## PANEL CONNECTOR



40pin connector, 30pin connector, 20pin pad, 10pin pad


The schematic diagram illustrates the logic circuit for the 74VHC08PW hex inverters. It features three inverters (U8A, U8B, U8C) and a NAND gate (U8D). The inputs are BKL\_EN (pin 1 of U8A), BLON (pin 2 of U8A), SB\_BLOH (pin 1 of U8B), LID\_SW# (pin 12 of U8D), and ALL\_SYS\_PWRGD (pin 13 of U8D). The outputs are VIN (pin 8 of U8C) and 3.3VS (pin 11 of U8D). The circuit is powered by 3.3V and 0.1uF capacitors (C43, C37). The logic is defined by the following equations:

$$VIN = \neg(SB\_BLOH)$$

$$3.3VS = \neg(BLON \wedge LID\_SW\# \wedge ALL\_SYS\_PWRGD)$$

\_\_\_\_\_

## FOR T




Schematic Diagrams

CRT

CRT PORT

Sheet 13 of 47  
CRT





**PantherPoint - M (HDA, JTAG, SATA)**

6-03-08265-050

**NO REBOOT STRAP**

**1TPM ENABLE/DISABLE**

**Flash Descriptor Security Override**

**ME ROM**

**BIOS ROM**

**SHARE ROM**

**NON-SHARE ROM**

**SATA HDD**

**eSATA**


**mSATA**

**TO DOCK HDD**

**Close to PCH**

**PCH 2/9**


Sheet 15 of 47  
Cougar Point M 2/9



## PCH 3/9

## PantherPoint -M (DMI, FDI, GPIO)


6-03-08265-0S0

Sheet 16 of 47  
PCH 3/9

**Sheet 17 of 47**  
**PCH 4/9**

PantherPoint -M  
(LVDS,DDI,CRT)








6-03-08265-0S0





[3,9,10,11,12,13,14,16,18,19,20,21,23,25,26,27,28,29,30,32,35,40] 3.3VS 

## B.Schematic Diagrams

**PCH 5/9**





**Sheet 18 of 47**  
**PCH 5/9**






PCH 6/9

Sheet 19 of 47  
PCH 6/9




PantherPoint - M (GPIO,VSS\_NCTF,RSVD)

6-03-08265-080



[14,15,16,18,21,23,25,26,30,34,35,37,38,42] VDD3  
[2,3,5,6,20,21,38,40] 1.05VS\_VTT  
[6,20,38] 1.8VS  
[2,3,6,11,14,15,18,23,24,27,29,30,35,36,38,39] 3.3V  
[3,9,10,11,12,13,14,16,17,18,20,21,23,25,26,27,28,29,30,32,35,40] 3.3VS

6-03-08265-0S0




Schematic Diagrams

PCH 8/9

Sheet 21 of 47  
PCH 8/9

CougarPoint power supply range		
Min	Voltage	Max
1.00V	1.05V	1.10V
1.43V	1.5V	1.58V
1.71V	1.8V	1.89V
3.14V	3.3V	3.47V
4.75V	5V	5.25V



## PCH 9/9


## PantherPoint -M (GND)

6-03-08265-0S0

6-03-08265-0S0



## NEW CARD (Port 3)



WLAN\_EN\_SW

3.3V

R472 30K\_04



R253 30K\_04

J\_SW2

2-3 ~>ON



1~2 ~>OFF

SSS-12M90APV-WF





# CCD, 3G

## MINI CARD 3G (Port 6)



Sheet 24 of 47  
CCD, 3G









Schematic Diagrams

TPM, HDD, USB3.0 CONN + PWR

Sheet 25 of 47  
TPM, HDD, USB3.0  
CONN + PWR




USB3.0 Conn + POWER




5V [24,31,35,36,38,39]  
VDD3 [14,15,16,18,19,21,23,26,30,34,35,37,38,42]  
VDD5 [12,13,21,28,29,35,40,41]  
3.3VS [3,9,10,11,12,13,14,16,17,18,19,20,21,23,26,27,28,29,30,32,35,40]

## KBC-ITE IT8518



LED, MDC

Sheet 27 of 47  
LED, MDC



**CODEC (ALC269 & VT1802P)**

**LAYOUT NOTE:**  
GND and AUDG space is 60mils - 100mils

**EMI Require**

**PC BEEP**

**Thermal Pad place 9 Via hole.**

**Please Let LC Filter together and close to Codec. IF Speaker wire length is less than 8000mils it don't need the LC Filter.**

**SPEAKER WIRE LENGTH LESS THAN 8000MILS. IT DON'T NEED LC FILTER.**  
SPKOUT+/- R, L+/-L Trace width  
Speaker 4 ohm ----> 40mils  
Speaker 8 ohm ----> 20mils


**WAVEFORMS:**  
3.3VS\_AUD  
5VS  
AZ\_RST#  
PD#

**COMPONENT VALUES AND TOLERANCES:**  
R431, R432: 0.04  
R433: 0.04  
R434: 0.04  
R435: 0.04  
R436: 0.04  
R437: 0.04  
R438: 0.04  
R439: 0.04  
R440: 0.04  
R441: 0.04  
R442: 0.04  
R443: 0.04  
R444: 0.04  
R445: 0.04  
R446: 0.04  
R447: 0.04  
R448: 0.04  
R449: 0.04  
R450: 0.04  
R451: 0.04  
R452: 0.04  
R453: 0.04  
R454: 0.04  
R455: 0.04  
R456: 0.04  
R457: 0.04  
R458: 0.04  
R459: 0.04  
R460: 0.04  
R461: 0.04  
R462: 0.04  
R463: 0.04  
R464: 0.04  
R465: 0.04  
R466: 0.04  
R467: 0.04  
C249: 10u, 16V, Y5V\_04  
C250: 10u, 16V, Y5V\_04  
C251: 10u, 16V, Y5V\_04  
C252: 10u, 16V, Y5V\_04  
C253: 10u, 16V, Y5V\_04  
C254: 10u, 16V, Y5V\_04  
C255: 10u, 16V, Y5V\_04  
C256: 10u, 16V, Y5V\_04  
C257: 10u, 16V, Y5V\_04  
C258: 10u, 16V, Y5V\_04  
C259: 10u, 16V, Y5V\_04  
C260: 10u, 16V, Y5V\_04  
C261: 10u, 16V, Y5V\_04  
C262: 10u, 16V, Y5V\_04  
C263: 10u, 16V, Y5V\_04  
C264: 10u, 16V, Y5V\_04  
C265: 10u, 16V, Y5V\_04  
C266: 10u, 16V, Y5V\_04  
C267: 10u, 16V, Y5V\_04  
C268: 10u, 16V, Y5V\_04  
C269: 10u, 16V, Y5V\_04  
C270: 10u, 16V, Y5V\_04  
C271: 10u, 16V, Y5V\_04  
C272: 10u, 16V, Y5V\_04  
C273: 10u, 16V, Y5V\_04  
C274: 10u, 16V, Y5V\_04  
C275: 10u, 16V, Y5V\_04  
C276: 10u, 16V, Y5V\_04  
C277: 10u, 16V, Y5V\_04  
C278: 10u, 16V, Y5V\_04  
C279: 10u, 16V, Y5V\_04  
C280: 10u, 16V, Y5V\_04  
C281: 10u, 16V, Y5V\_04  
C282: 10u, 16V, Y5V\_04  
C283: 10u, 16V, Y5V\_04  
C284: 10u, 16V, Y5V\_04  
C285: 10u, 16V, Y5V\_04  
C286: 10u, 16V, Y5V\_04  
C287: 10u, 16V, Y5V\_04  
C288: 10u, 16V, Y5V\_04  
C289: 10u, 16V, Y5V\_04  
C290: 10u, 16V, Y5V\_04  
C291: 10u, 16V, Y5V\_04  
C292: 10u, 16V, Y5V\_04  
C293: 10u, 16V, Y5V\_04  
C294: 10u, 16V, Y5V\_04  
C295: 10u, 16V, Y5V\_04  
C296: 10u, 16V, Y5V\_04  
C297: 10u, 16V, Y5V\_04  
C298: 10u, 16V, Y5V\_04  
C299: 10u, 16V, Y5V\_04  
C300: 10u, 16V, Y5V\_04  
C301: 10u, 16V, Y5V\_04  
C302: 10u, 16V, Y5V\_04  
C303: 10u, 16V, Y5V\_04  
C304: 10u, 16V, Y5V\_04  
C305: 10u, 16V, Y5V\_04  
C306: 10u, 16V, Y5V\_04  
C307: 10u, 16V, Y5V\_04  
C308: 10u, 16V, Y5V\_04  
C309: 10u, 16V, Y5V\_04  
C310: 10u, 16V, Y5V\_04  
C311: 10u, 16V, Y5V\_04  
C312: 10u, 16V, Y5V\_04  
C313: 10u, 16V, Y5V\_04  
C314: 10u, 16V, Y5V\_04  
C315: 10u, 16V, Y5V\_04  
C316: 10u, 16V, Y5V\_04  
C317: 10u, 16V, Y5V\_04  
C318: 10u, 16V, Y5V\_04  
C319: 10u, 16V, Y5V\_04  
C320: 10u, 16V, Y5V\_04  
C321: 10u, 16V, Y5V\_04  
C322: 10u, 16V, Y5V\_04  
C323: 10u, 16V, Y5V\_04  
C324: 10u, 16V, Y5V\_04  
C325: 10u, 16V, Y5V\_04  
C326: 10u, 16V, Y5V\_04  
C327: 10u, 16V, Y5V\_04  
C328: 10u, 16V, Y5V\_04  
C329: 10u, 16V, Y5V\_04  
C330: 10u, 16V, Y5V\_04  
C331: 10u, 16V, Y5V\_04  
C332: 10u, 16V, Y5V\_04  
C333: 10u, 16V, Y5V\_04  
C334: 10u, 16V, Y5V\_04  
C335: 10u, 16V, Y5V\_04  
C336: 10u, 16V, Y5V\_04  
C337: 10u, 16V, Y5V\_04  
C338: 10u, 16V, Y5V\_04  
C339: 10u, 16V, Y5V\_04  
C340: 10u, 16V, Y5V\_04  
C341: 10u, 16V, Y5V\_04  
C342: 10u, 16V, Y5V\_04  
C343: 10u, 16V, Y5V\_04  
C344: 10u, 16V, Y5V\_04  
C345: 10u, 16V, Y5V\_04  
C346: 10u, 16V, Y5V\_04  
C347: 10u, 16V, Y5V\_04  
C348: 10u, 16V, Y5V\_04  
C349: 10u, 16V, Y5V\_04  
C350: 10u, 16V, Y5V\_04  
C351: 10u, 16V, Y5V\_04  
C352: 10u, 16V, Y5V\_04  
C353: 10u, 16V, Y5V\_04  
C354: 10u, 16V, Y5V\_04  
C355: 10u, 16V, Y5V\_04  
C356: 10u, 16V, Y5V\_04  
C357: 10u, 16V, Y5V\_04  
C358: 10u, 16V, Y5V\_04  
C359: 10u, 16V, Y5V\_04  
C360: 10u, 16V, Y5V\_04  
C361: 10u, 16V, Y5V\_04  
C362: 10u, 16V, Y5V\_04  
C363: 10u, 16V, Y5V\_04  
C364: 10u, 16V, Y5V\_04  
C365: 10u, 16V, Y5V\_04  
C366: 10u, 16V, Y5V\_04  
C367: 10u, 16V, Y5V\_04  
C368: 10u, 16V, Y5V\_04  
C369: 10u, 16V, Y5V\_04  
C370: 10u, 16V, Y5V\_04  
C371: 10u, 16V, Y5V\_04  
C372: 10u, 16V, Y5V\_04  
C373: 10u, 16V, Y5V\_04  
C374: 10u, 16V, Y5V\_04  
C375: 10u, 16V, Y5V\_04  
C376: 10u, 16V, Y5V\_04  
C377: 10u, 16V, Y5V\_04  
C378: 10u, 16V, Y5V\_04  
C379: 10u, 16V, Y5V\_04  
C380: 10u, 16V, Y5V\_04  
C381: 10u, 16V, Y5V\_04  
C382: 10u, 16V, Y5V\_04  
C383: 10u, 16V, Y5V\_04  
C384: 10u, 16V, Y5V\_04  
C385: 10u, 16V, Y5V\_04  
C386: 10u, 16V, Y5V\_04  
C387: 10u, 16V, Y5V\_04  
C388: 10u, 16V, Y5V\_04  
C


Schematic Diagrams

POWER CON, FAN, TP, CLICK CON



FAN CONTROL



CLICK B'd CONN




FOR POWER SWITCH BOARD



[2,3,6,11,14,15,18,23,24,27,30,35,36,38,39] 3.3V  
[12,13,21,25,28,35,40,41] 5V  
[3,8,10,11,12,13,14,16,17,18,19,20,21,23,25,26,27,28,30,32,35,40] 3.3V

Sheet 30 of 47  
DOCKING  
CONNECTOR, COM  
PORT










Schematic Diagrams

AUDIO CONN, ESATA+USB+CHR

Audio Conn. & USB Charger components







ESATA+USB & POW




		CTL1	CTL2	CTL3
Mode 1	Power off & Discharge	0	0	0
Mode 2	Power off & Charge	0	1	1
Mode 3	Power off & Charge	1	0	1
Mode 4	Power on & Charge	1	1	1

## CARD READER JMC389



## Chip Note:

1. All component must be closed to chip in this block.
2. C70 place close to pin5 (Trace width/length: 10mil/<100mil) , C69 close to C70 (Trace width/length: 20mil/<100mil).
3. C73 place close to pin10 (Trace width/length: 10mil/<100mil)
4. Connect between Pin5 and Pin10 trace width/length: 20mil/<300mil
5. APREXT trace width/length: 10mil/< 250mil
6. C57 place close to pin18: 10mil/< 100mil for internal regulator usage






[14,15,16,18,19,21,23,25,26,30,34,35,37,38,42] VDD3  
[3,9,10,11,12,13,14,16,17,18,19,20,21,23,25,26,27,28,29,30,35,40] 3.3VS  
[2,3,6,11,14,15,16,23,24,27,29,30,35,36,38,39] 3.3V

Schematic Diagrams

LAN (INTEL LAN82579)

Sheet 33 of 47  
LAN (INTEL  
LAN82579)

GIGA LAN (INTEL LAN 82579)




NB RJ45

DOCKING RJ45

PD	SEL	FUNCTION
L	L	Ax to Bx , LEDAx to LEDBx
L	H	Ax to Cx , LEDAx to LEDCx
H	X	Hi - Z

[14,16,20,34,35] 3.3V\_M

## INTEL LAN 82579LM






Sheet 34 of 47  
INTEL LAN  
82579LM

	U25	U32	U28	U41	U27
VPRO	QM67 6-03-08267-0S1	82579LM 6-03-82579-030-S6	MX25L3206E 6-04-25320-490	MX25L3206E 6-04-25320-490	PM25LD010C-SCE 6-04-25010-A91
non-VPRO	HM65 6-03-08265-0S1	82579V 6-03-82579-031-S	NI	NI	MX25L3206E 6-04-25320-490

[21,35,36] 1.05V\_LAN\_M  
[14,15,16,18,19,21,23,25,26,30,35,37,38,42] VDD3

## 5VS, 3VS, 1.5VS CPU

Sheet 35 of 47  
5VS, 3VS, 1.5VS  
CPU




- 
- Diagram illustrating the mapping of 16 input lines to 16 output lines. The input lines are labeled 0 to 15. The output lines are labeled 0 to 15. The mapping is as follows:
- Input 0 maps to Output 1
  - Input 1 maps to Output 2
  - Input 2 maps to Output 3
  - Input 3 maps to Output 4
  - Input 4 maps to Output 5
  - Input 5 maps to Output 6
  - Input 6 maps to Output 7
  - Input 7 maps to Output 8
  - Input 8 maps to Output 9
  - Input 9 maps to Output 10
  - Input 10 maps to Output 11
  - Input 11 maps to Output 12
  - Input 12 maps to Output 13
  - Input 13 maps to Output 14
  - Input 14 maps to Output 15
  - Input 15 maps to Output 16

Sheet 36 of 47  
Power 1.5V/  
0.75V,1.8VS




## VDD3, VDD5

Sheet 37 of 47  
VDD3, VDD5







Sheet 38 of 47  
POWER 1.05V  
LAN\_M



**POWER 0.85VS**

Sheet 39 of 47  
POWER 0.85VS




**Power V-CORE 1 B - 41**

Schematic Diagrams


Power V-CORE 2

Sheet 41 of 47  
Power V-CORE 2



2PCS MOSFET,180W~220W : 3PCS , 300W: 4PCS , 360W: 5PCS


## CHARGER



Sheet 42 of 47  
CHARGE, DC IN


## CLICK BOARD / FG

Sheet 43 of 47  
CLICK BOARD/ FG



The **TESD\_GND** trace has to be wide (> 20mil)

The path be marked in  
needs to be design to be short and at low impedance.



**USB PORT**

AUSBVCC\_CH

AR5

220u, 6.3V, 3.6"3.4"2

AC7

AC6

80 mil

AC5

6.1u, 16V, .Y5V\_04

AUSBVCC\_CH\_R

AUSB\_PN9

AUSB\_PP9

WCM2012F25-SHORT

AGND

AJ\_USB1

V+

DATA\_L

DATA\_H

GND

UAR25-04TFNZ

GND3

GND4

AGND

6-21-B49E0-104

6-21-B49C0-104


**PIR SWAP**








# DEBUG BOARD




PIN51 & PIN8 Swap Future for Huron River Platform Debug Card Used.  
 PIN46 & PIN12 Swap Future for Huron River Platform Debug Card Used.  
 PIN17 & PIN14 Swap Future for Huron River Platform Debug Card Used.  
 PIN19 & PIN16 Swap Future for Huron River Platform Debug Card Used.



## 4 bits 80 Port Debug Card




Near 74164 pin-14



Sheet 46 of 47  
 DEBUG BOARD

Power Sequence

Sheet 47 of 47  
Power Sequence



# Appendix C: Updating the FLASH ROM BIOS

## To update the FLASH ROM BIOS you must:

- Download the BIOS update from the web site.
- Unzip the files onto a bootable CD/DVD/USB Flash Drive.
- Reboot your computer from an external CD/DVD/USB Flash Drive.
- Use the flash tools to update the flash BIOS using the commands indicated below.
- Restart the computer booting from the HDD and press **F2** at startup enter the BIOS.
- Load setup defaults from the BIOS and save the default settings and exit the BIOS to restart the computer.
- After rebooting the computer you may restart the computer again and make any required changes to the default BIOS settings.

## Download the BIOS

1. Go to [www.clevo.com.tw](http://www.clevo.com.tw) and point to **E-Services** and click **E-Channel**.
2. Use your user ID and password to access the appropriate download area (BIOS), and download the latest BIOS files (the BIOS file will be contained in a batch file that may be run directly once unzipped) for your computer model (see sidebar for important information on BIOS versions).

## Unzip the downloaded files to a bootable CD/DVD/ or USB Flash drive

1. Insert a bootable CD/DVD/USB flash drive into the CD/DVD drive/USB port of the computer containing the downloaded files.
2. Use a tool such as Winzip or Winrar to unzip all the BIOS files and refresh tools to your bootable CD/DVD/USB flash drive (you may need to create a bootable CD/DVD with the files using a 3rd party software).

## Set the computer to boot from the external drive

1. With the bootable CD/DVD/USB flash drive containing the BIOS files in your CD/DVD drive/USB port, restart the computer and press **F2** (in most cases) to enter the BIOS.
2. Use the arrow keys to highlight the **Boot** menu.
3. Use the “+” and “-” keys to move boot devices up and down the priority order.
4. Make sure that the CD/DVD drive/USB flash drive is set first in the boot priority of the BIOS.
5. Press **F10** to save any changes you have made and exit the BIOS to restart the computer.



### BIOS Version

Make sure you download the latest correct version of the BIOS appropriate for the computer model you are working on.

**You should only download BIOS versions that are V1.01.XX or higher as appropriate for your computer model.**

Note that BIOS versions are not backward compatible and therefore **you may not downgrade your BIOS to an older version** after upgrading to a later version (e.g if you upgrade a BIOS to ver 1.01.05, you **MAY NOT** then go back and flash the BIOS to ver 1.01.04).

## BIOS Update

---

### Use the flash tools to update the BIOS

1. Make sure you are not loading any memory management programs such as HIMEM by holding the **F8** key as you see the message “**Starting MS-DOS**”. You will then be prompted to give “**Y**” or “**N**” responses to the programs being loaded by DOS. Choose “**N**” for any memory management programs.
2. You should now be at the DOS prompt e.g: **DISK C:\>** (C is the designated drive letter for the CD/DVD drive/USB flash drive).
3. **Type the following command** at the DOS prompt:

**C:\> Flash.bat**

4. The utility will then proceed to flash the BIOS.
5. You should then be prompted to press any key to restart the system or turn the power off, and then on again but make sure you remove the CD/DVD/USB flash drive from the CD/DVD drive/USB port before the computer restarts.

### Restart the computer (booting from the HDD)

1. With the CD/DVD/USB flash drive removed from the CD/DVD drive/USB port the computer should restart from the HDD.
2. Press **F2** as the computer restarts to enter the BIOS.
3. Use the arrow keys to highlight the **Exit** menu.
4. Select **Load Setup Defaults** (or press **F9**) and select “**Yes**” to confirm the selection.
5. Press **F10** to save any changes you have made and exit the BIOS to restart the computer.

### Your computer is now running normally with the updated BIOS

You may now enter the BIOS and make any changes you require to the default settings.